

PL - INSTRUKCJA AKTUALIZACJI FIRMWARU

Aktualizacje firmwaru należy przeprowadzić tylko w przypadku stwierdzenia nie prawidłowego działania myszy.

1. Uruchom plik „step 1.exe”
2. Program rozpocznie aktualizację automatycznie. Jeśli wyświetli się komunikat FAIL, należy odłączyć mysz od komputera i ponownie podłączyć.
3. Po poprawnym zakończeniu aktualizacji pojawi się komunikat PASS. Następnie należy odłączyć mysz od komputera i ponownie podłączyć.
4. Następnie uruchom plik step 2.exe
5. Program rozpocznie aktualizację automatycznie. Jeśli wyświetli się komunikat FAIL, należy odłączyć mysz od komputera i ponownie podłączyć.
6. Po poprawnym zakończeniu aktualizacji pojawi się komunikat PASS. Następnie należy odłączyć mysz od komputera i ponownie podłączyć.
7. Mysz jest gotowa do użycia

EN - FIRMWARE UPDATE INSTRUCTIONS

Firmware updates need to be done only in case if the mouse is not working correctly.

1. Open the file “step 1.exe”
2. The program will start update automatically. If FAIL is displayed, disconnect the mouse from the computer and reconnect.
3. After successful update the program appears PASS. Then disconnect the mouse from the computer and reconnect.
4. Then open the file “step 2.exe”
5. The program will start update automatically. If FAIL is displayed, disconnect the mouse from the computer and reconnect.
6. After successful update the program appears PASS. Then disconnect the mouse from the computer and reconnect.
7. Mouse is ready to use